


SNAP ATTACHMENT INSTRUCTIONS

1. Locate the upper snap position on the rope.



2. Slide the snap into the snap cover.



3. Squeeze the rope together and slip the loop through the eye of the snap.



4. Pull the loop over the snap.



5. Draw the rope tight.



6. Measure down the rope to the next snap location and repeat these steps for the remaining flag snaps. If you are flying two flags allow about three inches between the flags.

The snap location can be adjusted as needed if the size of flag ever changes.